

## **Liability Release**

The purchaser of this product agrees that the manufacturer of this product has no responsibility or liability for errors in installation and/or resulting injury and/or accidents resulting from or associated with use and/or installation of this product.

Purchaser agrees to release manufacturer from any and all liability for personal injuries including death and property losses or damage occasioned by, or in connection with any activity or accommodations for use and/or installation of this product, either professionally installed or self installed.

Purchaser furthermore agrees to hold harmless and indemnify said manufacturer organization(s) its directors, employees and agents, for any liability sustained by use and/or modifications of product or vehicle, including claims for damages, losses, injuries, and expenses arising out of or resulting from use of product.



1907 Woodland Ave.  
Coffeyville, KS 67337  
Phone: (620) 251-9100  
Fax: (620) 251-2622

# INSTALLATION INSTRUCTIONS

## BIGBOY BRACKETS

FOR 1997-2006 JEEP WRANGLER  
DRIVER'S SIDE

1. Remove and save the (4) bolts holding seat frame to the floor. These will be reused when installing the new brackets.
2. Remove seat from vehicle.
3. Attach the left driver's side bracket (L) to the floor using (2) of the 5/16" bolts (A) that were removed in step 1, through the (2) elongated slot holes in the bracket as shown. **Do not tighten at this time.** From the bottom side of the bracket place (2) 5/16" x 1" carriage bolts (B) in the elongated slots as shown with the threads pointing upwards.
4. Attach the driver's side right bracket (M) to the floor using (1) 5/16" bolt (C) and (1) 7/16" bolt (D) that was removed in step 1 through the (2) elongated slot holes in the bracket as shown. **Do not tighten at this time.** Place the 5/16" carriage bolt (B) in the rear slot of the left big boy bracket as done in step 3. The front of the right bracket should be moved as far to the right as the slot will allow. Now the (2) bolts holding the right bracket to the floor can be fully tightened.

5. Place the seat on the new brackets allowing the protruding carriage bolts to go through the seat frame. Once the seat frame is located with all three carriage bolts protruding through the seat frame place 7/16" Hex Head Grade 8 Bolt (E) with washer (P) down through seat frame. Below Bigboy bracket place another washer (P) with machine nut (N) on bolt (E) as shown in Fig. 1. The washers (I) may be placed over the carriage bolts and tightened using the appropriate machine nuts (J) that are provided. The 7/16" machine nut (N) is provided for the 7/16" Hex head Grade 8 Bolt. At this time fully tighten all of the remaining nuts and bolts.

Now that the installation is complete you should have approximately 4" more legroom for the driver's seat.




FIG. 1 DRIVERS SIDE INSTALLATION

1907 Woodland Ave.  
Coffeyville, KS 67337  
Phone: (620) 251-9100  
Fax: (620) 251-2622



# INSTALLATION INSTRUCTIONS BIGBOY BRACKETS FOR 1997-2006 JEEP WRANGLER PASSENGER'S SIDE

1. Remove and save the (4) bolts holding seat frame to the floor. These will be reused when installing the new brackets.
2. Remove seat from vehicle.
3. Remove the jack from the holder. When the installation is complete the jack will be held in place by the new BigBoy Brackets.
4. Attach the right passenger's side bracket (M) to the floor using (2) of the 5/16" bolts (A) that were removed in step 1, through the (2) elongated slot holes in the bracket as shown. **Do not tighten at this time.** From the bottom side of the bracket place (2) 5/16" x 1" carriage bolts (B) in the elongated slots as shown with the threads pointing upwards.
5. Attach the passenger's side left bracket (L) to the floor using (1) 5/16" bolt (B) and (1) 7/16" bolt (D) that was removed in step 1 through the (2) elongated slot holes in the bracket as shown. **Do not tighten at this time.** Place the 5/16" carriage bolt (B) in the rear slot as was done in step 4. The front of the left bracket should be moved as far to the left as the slot will allow. Now the (2) bolts holding the left bracket to the floor can be fully tightened.




FIG. 1 PASSENGER'S SIDE INSTALLATION

Now that the installation is complete you should have approximately 4" more legroom for the driver's seat.